


Deer Blocker™

Nixalite's® Deer Blocker Deer Fence System protects your property from nuisance deer and the problems they cause.



Deer Blocker Fencing - The best in the business

- 4" square mesh made from 36-ply, UV resistant polyethylene
- Each strand has a knotted breaking strength of 175 pounds
- A full 8ft high fence, available in 100 and 300ft lengths
- Inconspicuous fence - low visual impact on your property
- Lighter and less expensive than same size metal or wood fence
- 5/16" border woven into all 4 edges - no additional supports needed



EZ-Set Angle Posts - Economical deer fence post kit

No overhead post driving. Strong 1-1/4" angle posts are inconspicuous.

Includes 1-4ft Ground Post, 1-8ft Top Post and 2 bolts, washers & nuts. Simple set up. Drive ground post 2ft into the ground with post driver (sold separately). The top post bolts to it using the included hardware. Space every 10' to 20' along the perimeter of the deer fence enclosure. Use existing supports (trees & other objects) wherever possible.



Premium Posts - Premium deer fence post kit

No overhead post driving. System can be removed quickly if needed.

Includes 1-Premium 1-5/8" black tube post w/cap and 1-Ground Sleeve. Simple set up. Use the Sleeve Driver (sold separately) to set the ground sleeve. The premium post fits into the ground sleeve. Space every 10' to 20' along the perimeter of the deer fence enclosure. Use existing supports (trees & other objects) wherever possible.

Accessories - Everything needed to install your Deer Blocker Deer Fence

Net Ties: 7.5" long, UV resistant cable ties fasten fencing to posts. In 100 or 1,000 ct. bags.

Ground Sleeve: 30" long sleeve for installing premium posts. Sets post height of 8ft.

Ground Stakes: 12" long galvanized steel stakes secure bottom edge of fencing.

Ground Anchor: 17" long steel screw in anchors to reinforce corner posts.

Post Driver: Sets angle posts quickly. Protects post and your fingers.

Sleeve Driver: Steel plug used to install anchor sleeve. Protects sleeve from damage.

Questions? Contact Nixalite for current prices and availability on all Deer Blocker items.

- More Deer Blocker details on back -

Nixalite® of America Inc - ph 800.624.1189 - fx 800.624.1196 - www.nixalite.com

Why Use Deer Fencing?

Deer Problem:

Over development of rural areas forces wild deer into urban areas, leading to unexpected and unwelcome problems and conflicts.

- Deer can ruin landscaping, trees, seedlings and gardens.
- Deer parasites carry Lyme disease, Tularemia, Rocky Mountain Fever, etc.
- Deer can transmit diseases and parasites to you, your pets and livestock.
- Deer vs. auto accidents kill and injure thousands of people every year.

Deer Blocker Solution:

A deer fence enclosure provides a humane and discreet barrier that keeps deer out of sensitive areas without relying on chemicals or electricity.

- Protects everything from small gardens to golf courses.
- Keeps deer separated from livestock, horses, pets, etc.
- Can help in keeping deer away from busy roads and trails.


Why Deer Blocker is superior:

Deer Blocker is the best in the business because it offers the best value. It is long lasting, lightweight, very strong and easy to install. The 4" square mesh is nearly invisible and has very little wind loading. It is MANY times less expensive and less conspicuous than an all metal or wood fence.

Protect:

- Landscaping
- Nurseries
- Trees, shrubs
- Lawns, gardens
- Orchards
- Vineyards
- Sod farms
- Municipal parks
- Golf courses
- Cemeteries
- Ball fields
- Busy roads
- Livestock pens
- Stables, barns
- Grain storage
- Many more

Deer Blocker Installation Guidelines



Use Deer Blocker Deer Fencing to protect your entire property or just selected areas within it. Be sure to **completely enclose** the area.

Accurately measure the path of deer fence. Note any trees or existing objects that could be used to support the fence. Deer Blocker Deer Fence **must be supported every 10 to 20 feet**. If existing trees and objects are too far apart, install additional posts to maintain this spacing. If trees or objects are not available, use Nixalite's Deer Fence posts for the entire enclosure.

To install Nixalite's Deer Fence Posts, use the instructions included with the post. If needed, reinforce corner posts with cable and anchors.

Fasten the deer fence to existing supports with u-nails or similar hardware. Secure the fence every 12" along the support (from top to bottom). Pull the fence tight before fastening to the next support.

Fasten the fence to Nixalite posts by using Net Ties. Secure the fence every 12" along the post (from top to bottom). Pull the fence tight before fastening to the next post or support.

To prevent deer from pushing under the fence, stake the bottom edge of the fence to the ground every 3 to 4 feet using Nixalite's Ground Stakes.

Attach 16" long strips of Repeller Ribbon to the fence. Space them every 10 feet along the fence, 4ft up from the ground. This makes the fence more visible to deer and helps prevent collisions. Add strips of ribbon to any corner cables as well.

If you have any questions about the Deer Blocker Deer Fencing System, please contact Nixalite.



Nixalite® of America Inc
1025 16th Avenue, East Moline, IL. 61244
Protecting People & Property Since 1950

Ph: 800.624.1189 or 309.755.8771
Fax: 800.624.1196 or 309.755.0077
Website: www.nixalite.com
Email: sales@nixalite.com